



JSPORT PERFORMANCE ACCESSORIES

Phone: 866.343.5509

2017+ HONDA RIDGELINE/PILOT/PASSPORT SKID PLATE INSTALLATION

COMPONENTS INCLUDED	
(1) JSPORT Skid Plate #JSPP001	(1) Hardware Kit

PART #	DESCRIPTION
JSPP001	2017+ Honda Ridgeline/Pilot/Passport Skid Plate

HARDWARE INCLUDED	
(4) 6mm Bolts (4) Allen Hex Washers	(2) 10mm Bolts

TOOLS REQUIRED	
Jack Jack Stands Ratchet/Wrench	14mm Socket/Wrench 10mm Socket/Wrench H4 Socket

INSTALLATION



1. Start by locating and removing the OEM bolts. Use a 10mm socket/wrench for these bolts. (Shown above)



2. Locate and remove the two 14mm cross brace bolts. (Shown above)



3. Lift the skid plate in place and insert the 14mm cross brace bolts (with washers) back into place loosely allowing movement for the skid plate.



4. Using the provided 10mm hardware, locate the front holes and insert the provided hardware loosely allowing enough movement for adjustments.



5. Tighten bolts and torque to spec.



WWW.JSPORTUSA.COM

JSPORT PERFORMANCE ACCESSORIES
Phone: 866.343.5509



www.facebook.com/jsportusa
www.instagram.com/jsportusa